



IN8339

ULTI Rack+

2

**VAN
GUARD**





This FITTING INSTRUCTION is the property of VAN GUARD ACCESSORIES LTD. and must not be used for manufacturing purposes, copied nor communicated in any way to third parties without written permission from VAN GUARD ACCESSORIES LTD.
IN8339_B (CN:00356)

Van Guard Accessories Ltd
Fair Oak Close, Exeter Airport Business Park,
Exeter, Devon, EX5 2UL
www.van-guard.co.uk

VGUR-260


Ford Transit: 2014 on
L4H3 (LWB)
Twin Rear Doors





SUPPLIED COMPONENTS - CHECK ALL PARTS ARE PRESENT AND CORRECT BEFORE PROCEEDING (1 OF 2)

TOOLS REQUIRED


10MM X1



13MM X1



AS3549 X2
(3800 / A)




MA6118 X14




FX4241 X32



ME1622 X3




AS3548 X2
(3800 / B)




FX4008 X1




MA6145 X1



ME1623 X3



ME1628 X7
(1554mm)




FX4001 X2
(M8X40)




FX4235 X28
(M5X25)




ME0203 X8




AS3160 X1
(1540mm)




MA6007 X4




FX4248 X1
(T25)




MA6065 X8




AS3590 X1




MA6093 X14



FX4239 X32
(M8X20)




ME1620 X4




FX4016 X16
(M6)



AS3591 X1




ME0316 X14




FX4240 X32
(M8)




ME1621 X4



FX4042 X16
(M6X16)



ME0786 X8



FX4019 X8

(M8)




FX4020 X8

(M8)




FX4028 X8

(M8X25)




MA6018 X8




01

1L



X4

1R



X4




2L





X3

2R



X3

02




03

01


FX4248




+



02




04



04




1




X4

2




X3



03



11Nm





05




EN - STICK GASKETS TO ALL BRACKETS
 DE - KLEBEN SIE DIE DICHTUNG AN ALLEN HALTERUNGEN
 FR - COUSSINETS ADHÉSIFS À TOUS LES SUPPORTS
 NL - PLAK PAKKING OP ALLE BEUGELS
 ES - PEGA LAS ALMOHADILLAS A TODOS LOS SOPORTES
 IT - ADESIVI GUARNIZIONI A TUTTE LE STAFFE

SV - FÄST GUMMI PÅ ALLA FÄSTEN
 DA - KLÆB GUMMI PÅ ALLE BESLAG
 NO - PLIST GUMMI PÅ ALLE BRAKKETTER
 PL - NAKLEJ USZCZELKI DO WSZYSTKICH WSPORNIKÓW
 CS - PŘILEPTE TĚSNĚNÍ NA VŠECHNY DRŽÁKY




06




07



08




09



X14

10







X2





EN - INSERT X2 INTO ALL BARS
DE - X2 IN ALLE STANGEN EINFÜGEN
FR - INSÉRER X2 DANS TOUTES LES BARRES
NL - PLAATS X2 IN ALLE BARS
ES - INSERTAR X2 EN TODAS LAS BARRAS
IT - INSERIRE X2 IN TUTTE LE BARRE

SV - INFOGA X2 I ALLA STÄNGAR
DA - INDSÆT X2 I ALLE STÆNGER
NO - SETT X2 INN I ALLE TAKSTENGER
PL - WSTAW X2 DO WSZYSTKICH PRĘTÓW
CS - VLOŽTE X2 DO VŠECH TYČÍ


11




12




13




14




15




16




17




18




19




20




21




22




23




24




25



26





27




EN - TIGHTEN ALL OF THE CROSS BARS
 DE - ALLE QUERSTANGEN FESTZIEHEN
 FR - SERREZ TOUTES LES BARRES TRANSVERSALES
 NL - DRAAI ALLE DWARSBALK VAN HET DAK AAN
 ES - APRIETE TODAS LAS BARRAS TRANSVERSALES
 IT - STRINGERE TUTTE LE BARRE TRASVERSALI

SV - SKRU UPP ALLA KORSSTANGAR
 DA - SKRU ALLE TAGBØJLER OP
 NO - SKRU OPP ALLE TVERRSTENGER
 PL - DOKRĘCIĆ WSZYSTKIE POPRZECZKI
 CS - VŠECHNY PŘÍČNÉ TYČE SEŠROUJTE


28




29



30



31



32

X8

15Nm

33

Diagram 33 illustrates the correct mounting of a roof rack on a car. The diagram shows a car with a roof rack installed. A yellow tape measure is shown above the rack, indicating a distance of 5m / 16'. Red arrows indicate the distance from the center of the car to the center of the rack. A green arrow indicates the distance between the two mounting points.

34

X16


11Nm

35


FX4241

X32

36



37



38

